

Donning and Doffing

1. Place the shoulder belt on the right or on the left as it is handier for the wearer. The pressure gauge must be always visible.



2. Adjust the waist belt at the proper size.



3. Extract the mask with the connected demand valve from the pocket of the carrying bag.



4. Pass the neck strap behind the head and collapse flat the mask pocket.



5. Push the red button on the demand valve to ensure that it is in the "stand-by" position.



6. Open the cylinder valve at least two complete turns and check on the pressure gauge reading that the whistling sound of the audible warning device stops when the needle reaches 55 bar. After that, verify that a value close to the maximum filling pressure of the cylinder is displayed.





7. Put the mask on the face placing the chin in the chin cup first and then pull the mask over the head.



- 8/9. Pull the two head straps and then the cheek ones. Finally, stretch the front strap. After donning the mask as above described, inhale deeply to check the correct and smooth functioning of the respirator. Then, stop inhaling for few seconds to verify that no leakage of air is perceived.



10. After use, in order to remove the mask, loosen completely the head straps by using the adjustable buckles (according to 8/9) and slip the mask over the head.



11. Set the demand valve in the "stand-by" position, close the cylinder valve and press the red knob of the demand valve until all circuits are completely unpressurized.